

# Nitrocellulose Characterisation to Support High Explosive and Propellant Life Assessment


Paul Deacon

[paul.deacon@awe.co.uk](mailto:paul.deacon@awe.co.uk)

Explosive Materials Group, AWE

# Introduction


- Nitrocellulose is a complex, naturally derived polymer



- Reliable methods for molecular weight determination are not available
- Molecular weight changes will influence properties of formulated products
- We have developed a more robust chromatographic method to improve reproducibility of molecular weight measurements

# What Information can SEC Provide?

- Fundamental polymer characterisation from one experiment
  - different statistical moments of mwt distribution
    - $M_n$ ,  $M_w$ ,  $M_z$
- Conformational information for the polymer in solution
  - intrinsic viscosity,  $[\eta]$  (i.e.  $1/\rho$ )
  - Mark-Houwink  $K$ ,  $a$  values
    - $a > 1$ : polymer behaving as a rigid rod
    - $a < 1$ : polymer behaving as a gaussian coil
    - $a \ll 1$ : polymer poorly solvated or highly branched
- Hydrodynamic parameters
  - e.g. radius of gyration,  $R_g$



# Important Polymer Properties

- Statistical moments of a polymer's molecular distribution
  - $M_n$ ,  $M_w$ ,  $M_z$
  - $M_n$  is the 'common sense' average


## Nitrocellulose -

- typical of naturally occurring polymers
- broad distribution
- tailing toward lower molecular weight

$$M_n = \frac{\sum N_i M_i}{\sum N_i}$$

$$M_w = \frac{\sum N_i M_i^2}{\sum N_i M_i}$$


$$M_z = \frac{\sum N_i M_i^3}{\sum N_i M_i^2}$$



# Nitrocellulose Analysis

- Nitrocellulose molecular weight measurement is very challenging
    - High viscosity
    - Natural variability
    - Poor refractive index in common solvents
- } Not suited to SEC
- Results are often difficult to reproduce
  - Usefulness of data for (e.g.) kinetics analysis can be severely comprised by variability
  - We have succeeded in defining analysis conditions to 'control' this variability

# Nitrocellulose Dissolution



## Different Solvents..?

- Acetone gives complex chromatography
  - Are these effects real?
- Ethyl acetate similar to THF
  - Dissolution more rapid
- Calibration standards not easily available

# SEC Experimental Conditions

- Optimised conventional (concentration) detection

Nitrocellulose Concentration	1.5 mgcm <sup>-3</sup>
Dissolution time	7 days at ambient temperature
Mobile Phase	BHT stabilised THF (100 ppm) @ 1 cm <sup>3</sup> min <sup>-1</sup>
SEC Column(s)	2 x 30 cm PLGel 10 μm Mixed-B styrene-divinyl benzene
Standards	PL Easical A/B Polystyrene
Column Temperature	35 °C

- Method evaluated statistically...




# Reproducibility of Results

Sample	$M_n$ (dalton) ( $\pm 1$ s.d)	$M_w$ (dalton) ( $\pm 1$ s.d)	$M_w/M_n$ ( $\pm 1$ s.d)
Propellant Grade (Wimmis 12.6 % N)  1.0 mg cm-3	228800 $\pm 22100$  ( $\pm 9.6$ %)	806000 $\pm 40800$  ( $\pm 5.1$ %)	3.575 $\pm 0.586$  ( $\pm 16.4$ %)
Propellant Grade (Wimmis 12.6 % N)  1.5 mg cm-3	213500 $\pm 22400$  ( $\pm 10.5$ %)	597500 $\pm 21100$  ( $\pm 3.5$ %)	2.842 $\pm 0.443$  ( $\pm 15.6$ %)
Propellant Grade (Wimmis 12.6 % N)  2.0 mg cm-3	156300 $\pm 47200$  ( $\pm 30.2$ %)	518300 $\pm 40400$  ( $\pm 7.8$ %)	3.840 $\pm 1.704$  ( $\pm 44.4$ %)



30 replicate analyses of the *same* nitrocellulose solution

# Molecular Weight : Concentration



# What Materials Require Characterisation?

- Nitrocellulose based HE, e.g. PBX(A):-
  - 91 % (w/w) HMX as explosive filler (crystals < 100 µm)
  - 9 % (w/w) gelatinous visco-elastic binder

Binder {  
1 % (w/w) high viscosity lacquer grade nitrocellulose  
8 % (w/w) aromatic nitroplasticiser  
0.02 % (w/w) stabiliser (ethylcentralite)

- Nitrocellulose based propellants
  - Double base propellant
  - Triple base gun propellant
- Other nitrocellulose products
  - Inks, lacquers, paints, specialist coatings





PBX(A)

# Arrhenius Kinetics Analysis

- Thermal acceleration causes nitrocellulose molecular weight decrease
  - Ageing data acquired from 7 years multidisciplinary effort !

$$\frac{1}{M_n(t)} = \frac{1}{M_n(0)} + kt$$




- Arrhenius kinetics used to parameterise nitrocellulose chain scission

# Kinetics of Nitrocellulose Degradation


- Point-by-point technique used to stabilise calculated values of  $E_a$ ,  $A$ , extrapolated  $\ln(k)$
- Arrhenius regression predicts  $\ln(k)$  over a wide temperature range (with  $\pm 95\%$  limits)

$\ln(k)$



# What is the Significance?

- PBX(A) moulding powder is isostatically pressed to high density (~ 98 % TMD)
  - pristine, unaged material remains brittle and weak
- Time further weakens PBX(A) due to reduction in nitrocellulose molecular weight



## Collaboration with DCMT

- We are working in collaboration with DCMT, Cranfield University
- SEC methods are being used to characterise nitrocellulose extracted from DB and TB propellants
  - Unaged
  - Aged
- Phil Gill presentation “ Whole Life Assessment of Nitrocellulose in Rocket and Gun propellants”
  - Wednesday morning...

# Conclusions

- Nitrocellulose analysis remains a challenge
- We have evaluated an SEC method for molecular weight determination
- The results of this analysis have successfully been used to characterise a high explosive
  - Arrhenius kinetics analysis performed
- The method is transferable to DB and TB propellants



# Acknowledgements

Carole Baker                      DOSG, UK MoD, Bristol  
(supporting nitrocellulose characterisation)

Phil Gill                              DCMT, Cranfield University

John Bellerby                      DCMT, Cranfield University

Alan Macdonald                      Explosives Materials, AWE

Louise Byers                      Explosives Materials, AWE

Jessica Gwyther \*                      Explosives Materials, AWE

*\* Now University of Bristol, UK*